



FIRST FENCE USA

WE LISTEN. WE CARE. WE DELIVER

Little Beaver Replacement Parts & Assemblies

Specification Sheet

SPC-LITB-007A

Little Beaver Replacement Parts & Assemblies

Explore our specialized inventory of authentic Little Beaver drive components and clutch assemblies built to keep your earth drilling equipment running at peak performance. This carefully curated selection features essential powertrain parts, from complete flexible shafts and keyed auger adaptors to heavy-duty clutch drums and fiber-lined rotor upgrades. Whether you are performing routine maintenance or executing a complete clutch change-over, these premium replacement parts ensure reliable torque transfer, smooth engagement, and long-lasting durability.

Little Beaver Flexible Shaft Assembly Complete Suhner 020-000027

Product Type	Shaft Assembly
Internal Material	Nickel-Super Alloy
External Material	Heavy-Duty Rubber
Color	Black
Compatibility	Little Beaver Earth Drills
Maintainance	Up to 50 hours before needing grease



Little Beaver Rotor Assembly - Model 5 - 3/4" Bore w/ Fiber Lined Shoes Incl. Key 020-000030

Product Type	Rotor Assembly
Bore Size	3/4" Bore
Shoe Type	Fiber Lined
Blade Type	No



Little Beaver Rotor Assembly - Model 7/8 1" Bore w/ Fiber Lined Shoes Incl. Key 020-000031

Product Type	Rotor Assembly
Bore Size	1" Bore
Shoe Type	Fiber Lined Shoes
Blade Type	No



Little Beaver Change-Over Kit - Clutch 5HP 3/4 Bore w/Fiber Shoes & Drum 020-000032

Engine/Horespower	5HP
Compatibility	
Bore Size	3/4"
Included Components	Clutch with Fiber Lined Shoes
Blade Type	No



Little Beaver Change-Over Kit - Clutch 8HP 1" Bore w/Fiber Shoes and Drum 020-000033

Engine/Horsepower	8HP
Compatibility	
Bore Size	1" Bore
Included Components	Clutch With Fiber Lined Shoes
Blade Type	No



Call our Expert Sales Team for more information

www.firstfenceusa.com | sales@firstfenceusa.com | (945) 941-2111